






Plate Turning Instructions




- Before each turn, ensure the plate is clean.
- You will need the turning key provided.




- Holding the plate shiny side up, you will notice a small hole and a yellow arrow pointing down.



- Insert the turning key into the hole at the top of your plate.



- Turn the key all the way down in the direction of the yellow arrow.
- Once you can not turn the key further you have completed a full turn.



- After several weeks you should start to notice a small gap forming between the two acrylic halves.
- If you do not notice a gap forming, revisit these instructions or contact us.